



Details & Accessories

Hebo Halter® Super Power Collar



Hebo Halter® Plus Collar



◀ Hebo Halter® Table Mount and Clamp



Hebo Halter® mounting device holds 2 collars ▶



◀ Hebo Halter® Tripods are adjustable making sleeving easy and ergonomic



◀ Hebo Halter® Spacer regulates and can be adjusted for any stem length or finished plant height



HEBO HALTER® PLUS

Item Code Description

Hebo Halter® Plus 26
 Hebo Halter® Plus 32
 Hebo Halter® Plus 38
 Hebo Halter® Plus 42
 Hebo Halter® Plus 50
 Hebo Halter® Plus 60

Applicable Sleeve Sizes (top opening)

7.875 - 11 inches
 7.85 - 11 inches
 11.8 - 15.75 inches
 15.75 - 19.7 inches
 17.7 - 19.7 inches
 19.7 - 27.5 inches

HEBO HALTER® SUPER POWER

Item Code Description

Hebo Halter® Super Power 32
 Hebo Halter® Super Power 38
 Hebo Halter® Super Power 42
 Hebo Halter® Super Power 60
 Hebo Halter® Super Power 75

Applicable Sleeve Sizes (top opening)

7.85 - 13.8 inches
 11.8 - 15.75 inches
 15.75 - 19.7 inches
 19.7 - 27.5 inches
 27.5 - 31.5 inches

COMMON ACCESSORIES (OTHERS AVAILABLE ON REQUEST)

Item Code Description

Hebo Halter® Table Model 2601
 Hebo Table Clamp
 Hebo Standard Tripod
 Hebo Standard Tripod w/wheels
 Hebo Mini Tripod (table top)
 Hebo Halter® Spacer (holds pack bottom)
 Hebo Halter® Two-Sided Head Holder

Dimensions (if applicable)

7.85 - 11 inches
 Fits any Hebo Halter® Head
 Fits any Hebo Halter® Head
 Fits any Hebo Halter® Head
 Fits any Hebo Halter® Head
 Fits any Hebo Halter® Head
 Fits any Hebo Halter® Head